

## **Starter Tool Instructions**



| SF-ST1        |               |               | SF-ST2         |                | SF-ST3                       |
|---------------|---------------|---------------|----------------|----------------|------------------------------|
| Fits:         |               |               | Fits:          |                | Fits:                        |
| A-1           | Innova        | Pennywinkle/  | APQS           | Gammill        | <b>Empress-Original Foot</b> |
| Babylock      | Ken Quilt     | Roll 'N Glide |                |                | GrandQuilter 18.8            |
| Jewel         | Juki Virtuoso | Quartermaster | Empress-       | Tin Lizzie-    | Tin Lizzie-Original Foot     |
| Handi Quilter | Nolting       | Voyager       | Template/Ruler | Template/Ruler | Viking Megaquilter 18x8      |
| Indigo        | Prodigy       |               | Foot           | Foot           |                              |

The Starter Tool is an excellent tool to learn eye-hand coordination when you first start using your new machine. Slip the tool over the hopping foot, with one hand on the handle of the machine and the other on the Starter Tool you can now guide your machine. With one hand closer to the needle, it is easier to learn to maneuver your machine. Later, you will find the tool is useful as a guide to create shallow concave curves, as a straight edge, or as a handle that moves the foot.

## To use the Starter Tool:

- 1) Place tool on right\* side of foot at a 45° angle.
- 2) Slide opening of tool between the back of the foot and needle until foot fits into circular opening.
- 3) Grasp tool to guide your foot around your quilt.
- \* If left-handed place the tool on the left side of foot and continue with the instructions. Hopping Foot

The Starter Tool can also be used as a straight edge, stitch in the ditch aid, pusher to steady foot, and the shallow curve can be used as a continuous line tool.

